
**ШПРИЦ КОЛБАСНЫЙ АВТОМАТИЧЕСКИЙ HURAKAN HKN-ISA26**



**ШПРИЦ КОЛБАСНЫЙ АВТОМАТИЧЕСКИЙ HURAKAN HKN-ISA26**

| Поз | Наименование детали |
|---|---|
| 1 | Motor |
| 2 | Flange |
| 3 | Motor Connector |
| 4 | Oil seal |
| 5 | Oil box cap |
| 6 | Oil box plate |
| 7 | Oil pump connector |
| 8 | Oil pump |
| 9 | Filter |
| 10 | Oil box |
| 11 | Screws |
| 12 | External Gasket for oil tank piston |
| 13 | Oil tank piston |
| 14 | Internal Gasket for oil tank piston |
| 15 | Piston Rod |
| 16 | External gasket for Guide sleeve |
| 17 | Guide sleeve |
| 18 | Internal gasket for guide sleeve |
| 19 | Dust cover |
| 20 | Internal gasket for dust cover |
| 21 | Piston Support frame |
| 22 | Plunger/piston |
| 23 | Gasket for piston |
| 24 | Top cover |
| 25 | Spring |
| 26 | Oil tank |
| 27 | Oil tank connector |
| 28 | Gasket for oil tank connector |
| 29 | Magnetic valve |
| 30 | Overflow valve |
| 31 | Circuit block |
| 32 | Support frame |
| 33 | Side plate |
| 34 | Support frame |
| 35 | Fuse |
| 36 | Transformer |
| 37 | Foot pedal |
| 38 | Stuffing nozzle |
| 39 | Gasket for nozzle |
| 40 | Trefoil nut |
| 41 | cylinder Locking Screw |
| 42 | Gasket for cylinder |
| 43 | Cylinder |
| 44 | Bar |
| 45 | Bar |
| 46 | Plate |
| 47 | Support plate |
| 48 | Relay |
| 49 | Timer |
| 50 | Switch |
| 51 | Emergency switch |
| 52 | Overload protection |
| 53 | Main body |
| 54 | Throttle valve |
| 55 | Castors |
| 56 | Back cover |
| 57 | Universal castors |