
**РИСОВАРКА HURAKAN HKN-SDR80**



**РИСОВАРКА HURAKAN HKN-SDR80**

| Поз | Наименование детали |
|---|---|
| 1 | Lid handle |
| 2 | Lid |
| 3 | Pot liner |
| 4 | Insulation board |
| 5 | cabinet |
| 6 | handle |
| 7 | Ceramic terminal block |
| 8 | Insulation board support board |
| 9 | Machine foot |
| 10 | Power cord plug |
| 11 | Contact switch mounting plate |
| 12 | Contact switch |
| 13 | Contact switch rocker mounting plate |
| 14 | Power cord lock |
| 15 | Contact switch rocker |
| 16 | Joystick handle |
| 17 | Electrical box |
| 18 | Y-type thermostat switch |
| 19 | Y-type temperature control switch mounting plate |
| 20 | Support plate for over-temperature fuse |
| 21 | Over temperature fuse |
| 22 | Magnetic steel temperature limit switch |
| 23 | Magnetic steel temperature limit switch top plate |
| 24 | Electric heating tube 1 |
| 25 | Electric heating tube 2 |
| 26 | Electric heating tube 3 |
| 27 | Thermal pad |
| 28 | Bottom seal |
| 29 | Circuit board |