
Наш сайт: www.robotcoupe.ru
Телефон в Москве:+7(495)795-94-34


C120 - C200


S/N = - X X X - - - - - - -
X X X = 003, 032, 495





ATTENTION : Les anciens moteurs type D32 ne sont plus disponibles.
WARNING: Old motors type D32 are no longer available.

Ancien moteur type D32 à remplacer ? / Old motor D32 to be changed ?	Commandez : / Order :	Vous recevrez : / You will receive :
D32	29 138 ou/or 29 142 ~~ou/or 29 143~~ ou/or 29 210 ou/or 29 211 ou/or 29 141 (Kit de mise à Niveau) / (Upgrade Kit)	D29 Z X Y1 24 30-31-32 C 25 Câbles et notice / Wires and technical instructions









robot coupe

C 120

Diagram n°1

Index PDF	Référence	Designation commerciale
A	404080	[Spare parts translation not found]
B	503978	POWER CORD
C Type D29 s/n495	507256	OVERLOAD RELAY LRD 10 TESYS
M1 Type D29 s/n495	39493	MOTOR
M2 TypeD32 s/n032	29143	MOTOR ASSEMBLY
X	600087S	CONDO ASSEMBLY 100ÁF 250V
Y1 Type D29 s/n495	~~504127~~ 504127S	RELAY
Y2 Type D32 s/n032	5140320	[Spare parts translation not found]
Z	~~502473~~ 502473S	CAPACITOR
1	59017	COMPLETE TOOL
2	59548	SCRAPER FIXING ASSEMBLY C120/C200
3	59549	SCRAPER ASSEMBLY C120/C200 (Qty=2)
4	39495	KNURLED KNOB C120
5	141790S	C120/200 HOPPER
6	~~141780S~~ 141780	[Spare parts translation not found]
7	~~508080S~~ 508080	[Spare parts translation not found]
8	~~507683S~~ 507683	[Spare parts translation not found]
9	~~121836S~~ 121836	[Spare parts translation not found]
10	29134	MOTOR SUPPORT ASSEMBLY
11	~~507694S~~ 507694	[Spare parts translation not found]

12	~~101060S~~ 101060	[Spare parts translation not found]
13	~~29050~~ 59169	REED SWITCH
14	~~503491S~~ 503491	[Spare parts translation not found]
15	59020	LEGS ASSEMBLY
16	59550	[Spare parts translation not found]
17	57211	PERFORED BASKET 0.5MM
18	57145	PERFORED BASKET 1MM
19	57019	PERFORED BASKET 2MM
20	57156	PERFORED BASKET 3MM
21	57020	PERFORED BASKET 5MM
23	~~121748S~~ 121748	[Spare parts translation not found]
24	208582S	MOTOR SHAFT PIN
25	39496	CONTACTOR SUPPORT
26	~~509091S~~ 509091	[Spare parts translation not found]
27	~~121847S~~ 121847	[Spare parts translation not found]
28	59077	SCREW CAP (X4)
29	~~504728S~~ 504728	[Spare parts translation not found]
30	~~504703S~~ 504703	[Spare parts translation not found]
31	~~504702S~~ 504702	[Spare parts translation not found]
32	~~504701S~~ 504701	[Spare parts translation not found]
33	500806S	[Spare parts translation not found]
34	501116S	BALL BEARING

35	504240S	BALL BEARING 6005 2RS
36	502678S	BEARING 6205
37	59664	[Spare parts translation not found]
38	57036	FRONT NAME PLATE
39	39320	BRAKE ROLLER D100
40	203014S	[Spare parts translation not found]
41	204370S	[Spare parts translation not found]
42	118703S	[Spare parts translation not found]