ELECTRONIC **LUXO**MATIC 55dB USER MANUAL.

CARRETERA DE SANTA COLOMA, S/N
APARTADO DE CORREOS Nº 18
17410 SILS-MALLORQUINES (GIRONA) SPAIN T
+34 972 16 82 82 · F +34 972 85 31 04
cunill@cunill.com · **www.cunill.com**

1
_1 Coffee
_Reduction of the grinding time
_Menu selection

2
2 Coffees
_Increase of the grinding time
_Menu selection

3
_Continuous coffee
_Screen selection

4
_Chronometer
_Access to the menu





START-UP OF THE GRINDER:
Connect the grinder to the network and turn it on by pressing the main switch.

LANGUAGE SELECTION: To access the language selection press button No. 4 twice and then press simultaneously button No. 1 and No. 2 during 4 seconds.
(LANGUAGE) (1 – BEAT – 1 COFFEE) (2-BEATS – 2 COFFEES) **(COUNTER)**
To select the language press buttons No. 1 or No. 2 until the desired language appears.
Once selected it needs no confirmation.

_ 1 COFFEE: Press button No. 1 to get one dose of ground coffee.

_2 COFFEES: Press button No. 2 to get two doses of ground coffee.


_CONTINUOUS COFFEE: To get a customized ground coffee dose keep pressed button No. 3 until obtain the desired quantity

_PROGRAMMING COFFEE: To access the programming of the grinding time for 1 or 2 coffees press button No. 4 twice and then simultaneously press button No. 1 and No. 2 for 4 seconds. Pressing button No. 3 see on the display the desired section:
(LANGUAGE) **(1-BEAT – 1 COFFEE)** or **(2-BEATS – 2 COFFEES)** (COUNTER).
To increase or decrease the grinding time press button No. 1 (to decrease) or No. 2 (to increase).
Once selected it needs no confirmation.

COFFEE COUNTER: To access the programming of the coffee counter press button No. 4 twice and then simultaneously button No. 1 and No. 2 during 4 seconds. Pressing button No. 3 select the desired section visualized on the display:
(LANGUAGE) (1 – BEAT – 1 COFFEE) (2-BEATS – 2 COFFEES) **(COUNTER)**
See on the screen the whole quantity of coffees made.
Pressing buttons No. 1 and No. 2 at the same time the counter will be set to zero.



GRINDING SETTING ACCORDING TO THE COFFEE MACHINE USED
To make a perfect espresso: Press button No. 4 of the coffee grinder with one hand while pressing at the same time the button for coffee on the coffee machine. Release immediately button No. 4.
Once the coffee is made press again button No. 4 to stop the chronometer and see on the display the seconds it took to make one coffee.
According the table below the calibration will be modified.



15" to 20" (very coarse grinding) WRONG COFFEE
20" to 25" (fine grinding) RIGHT COFFEE
25" to 30" (very fine grinding) WRONG COFFEE





Dose selection by placing the coffee holder on the wedge for filling the selected ground coffee.






Once filled with ground coffee the holder is placed on the lower end of the grinder (fitting*) and the tamper is used to get a proper pressing.
* The tamper can be located on the right or left according to the barista needs.