

L1
L2
L3
N
L1
L2
L3
L2
L1
L3
7
8
9
10
11
REMOTE CTRL SWITCH
REMOTE CTRL SWITCH
U1
V1
W1
L1
L2
L3
A
S
C
MC cover
MC2
MC2
PT
PT
MC1
MC1
MC tank
REMOTE CTRL SWITCH
REMOTE CTRL SWITCH
M
3~
U2
V2
W2
7 8 9 101112
TRANSFORMER
C
S
A
SUPPLY POWER BOARD
PUSH–BUTTON CONTROL BOARD