
МИКСЕР ПЛАНЕТАРНЫЙ HURAKAN HKN-IP20FM



МИКСЕР ПЛАНЕТАРНЫЙ HURAKAN HKN-IP20FM

Поз	Наименование детали				
1	Screw	58	Screw	115	Barrell holder
2	Cover	59	Rear	116	Flat clamp
3	Nut	60	Screw	117	Screw
4	Washer	61	Motor Fan	118	Locking pin
5	Bearing plate pinch 2	62	Bake Cover	119	Screw
6	Bearing	63	Bearing	120	Washer
7	Oil-lide cover	64	Bottom plate	121	Screw
8	Bearing cap	65	Centrifugal switch	122	Ring washer
9	Screw M	66	Screw	123	Guide pillar
10	Bearing	67	Stator	124	Nut
11	Washer	68	Rotor	125	Washer
12	Nut	69	Dowel	126	Washer
13	Screw	70	Bearing	127	Pin
14	Nut	71	Oil Seal	128	Cam
15	Washer	72	Main transmission worm	129	Cotter pin
16	Bearing plate pinch 1	73	Ring washer	130	Lifeing hook
17	Bearing	74	Nut	131	Straight Pin
18	Cam splint	75	Case	132	Screw
19	Gear rim	76	Viewport Cover	133	Capacitor
20	Cam	77	Screw	134	Screw
21	Leaf Spring	78	Sleeve	135	Capacitor
22	Cylindrical roller	79	Oil seal	136	Plate
23	Cam circle	80	Ring gear	137	Ball
24	Gear	81	Screw	138	Lifting crank
25	Sliding collar	82	Planetary Gear Holder	139	Sleeve
26	Conjugant	83	Washer	140	Resilient pin
27	Center shafe	84	Nut	141	Lifting sleeve
28	Dowel	85	Ring	142	Screw
29	Dowel	86	Wire Whip	143	Ring washer
30	Dowel	87	Charging barrel	144	Screw
31	Sliding collar	88	Dough mixer	145	Footing
32	Gear	89	Agitator		
33	Spacer Sleeve	90	Straight pin		
34	Bearing	91	Planetary gear shaft		
35	Regulating Nut	92	Dowel		
36	Spring	93	Oil seal		
37	Fork contact	94	Bearing		
38	Nut	95	Bearing		
39	Ring washer	96	Planetary gear		
40	Shift fork	97	Washer		
41	Fork Shaft	98	Nut		
42	Regulating Nut	99	Posicioning spring		
43	Spring	100	Steel ball		
44	Shift fork	101	Label		
45	Bearing	102	Switch		
46	Snap spring	103	Screw		
47	Gear	104	Conical pin		
48	Snap spring	105	Knee-piece		
49	Gear	106	Locating Cover plate		
50	Dowel	107	Screw		
51	Dowel	108	Hinge pin		
52	Second motion shaft	109	Conical pin		
53	Input shaft	110	Locating sleeve		
54	Dowel	111	Shiftfork handle		
55	Worm	112	Nut		
56	Snap spring	113	Spring washer		
57	Bearing	114	Anchor Pin		