
Наш сайт: www.robotcoupe.ru
Телефон в Москве:+7(495)795-94-34

R 45 A
R 45 A V.V.

N° de série / Serial number
- 612 - - - - - - -
- 624 - - - - - - -



Maj : 09/2021 | REV : k

robot coupe

R45A

Diagram n°1

Index PDF	Référence	Designation commerciale	Tarif
A	117995	CONTROL PANEL ASSEMBLY R45/R60 400/50	
B	59160	POWER CORD PROTECT	
C	504272S	POWER CORD 4X6 MM²	
D	59145	SWITCH COMMAND PANEL ASSEMBLY	
M	303064S	MOTOR ASSY R45 400/50/3	
1	59128	HINGE ASSEMBLY	
2	59273	LID ARM SAFETY	
3	501258S	POSIT SAFETY BUTTON	
4	507250S	SAFETY BUTTON (2PTS)	
5	118255S	HINGE FLAT SEAL	
6	105912S	VCM G3 SAFETY SWITCH CAM	
7	118126S	HINGE BUSH	
8	118126S	HINGE BUSH	
9	119208S	RIGHT LID TUBE R45	
10	119209S	LEFT LID TUBE R45	
11	59511	LID WIPPER ASSEMBLY	
12	59395	BLX8-20 SCRAPER ARM HANDLE	
13	59512	FLEXIBLE LID SCRAPPERS (X2)	
14	59513	LID WIPPER SUPPORT	
15	59505	LID SUPPORT ASSEMBLY	
16	59504	LID SUPPORT	
17	118132S	ARM REED SWITCH VCM	
18	59131	ARM CLIP ASSEMBLY	
19	57081	STRAIGHT BLADE	
20	57082	COARSE SERRATED BLADE	
21	57084	FINE SERRATED BLADE ASSEMBLY	

22	105905S	R45/R60 BLADE LOCKING
23	105907S	R45/R60 PLASTIC WASHER
24	118204S	BLADE SPACER 14MM
25	117952S	R45 STRAIGHT BLADE
26	118205S	BLADE SPACER 43MM
27	117932S	BLADE SUPPORT R45
28	118243S	R45 FINE SERRATED BLADE
29	118287S	COARSE SERRATED BLADE
30	118268S	R45 KNIFE TOOL
31	119200S	KNIFE TOOL
32	117940S	CASING ACCESS DOOR R45/60
33	118257S	SEAL DOOR R45/R60
34	118127S	ARM SAFETY WIRING
35	59135	TILTING BACK AXLE ASSEMBLY
36	118146S	BACK TILTING PIVOT SPACER
37	118147S	BACK THRUST WASHER
38	118148S	BACK BEARING BUSH
39	117959S	TILTING THRUST
40	507250S	SAFETY BUTTON (2PTS)
41	117939S	CASING R45/R60
42	118186S	CASING FOOT VCM
43	59313	LID CONE
44	59318	LID SUPPORT
45	119259S	LID LATCH RUBBER STOP
46	119267S	LID LATCH G3
47	59272	VCM LID HANDLE ASSEMBLY
48	59519	LID

49	119265S	R45 G3 LID SEAL
50	59142	BOWL ASSEMBLY
51	118171S	COMPLETE SAFETY PLUG
52	59222	SHAFT SEALS ASSEMBLY
53	59168	SHAFT TOP SEAL RING ASSEMBLY
54	118153S	BOWL SEAL
55	507054S	LIP SEAL 40X52X7
56	507050S	O RING
57	59165	BOWL THRUST ASSEMBLY
58	118595S	BOWL SUPPORT VCM
59	59143	SEALING SOCKET ASS
60	118175S	UPPER MOTOR COVER R45
61	118174S	MOTOR DEFLECTOR
62	59198	MOTOR SUPPORT ASSEMBLY
63	118157S	MOTOR SUPPORT REED SWITCH
64	119199S	BOWL SAFETY SWITCH
65	119194S	BOWL SAFETY SWITCH HARNES
66	59223	TILTING PIVOT STAPLE ASSEMBLY
67	118297S	R45 BOTTOM MOTOR COVER
68	118150S	SLEEVE BUSH
69	118149S	SLEEVE 107MM R30/R45
70	59137	TILTING FRONT AXLE ASSEMB
71	117941S	STAND R45
72	117958S	STAND FOOT VCM
73	59138	TILTING LOCKING ASSEMBLY
74	118142S	HANDLE VCM
75	208582S	MOTOR SHAFT PIN

76	59440	MOTOR RING KIT
77	118143S	FRONT THRUST WASHER
78	118144S	FRONT HEASING BUSH
79	59551	VCM TILTING AND TIGHTENING SET
80	59552	FRONT COVER KIT VCM
81	59495	LID ANS SEAL ASSEMBLY
82	59204	REAR CASTOR ASSEMBLY (NM)
83	59210	SLANTED CASTOR ASSEMBLY (NM)
84	59203	FRONT CASTOR ASSEMBLY (NM)
86	59008	ADJUSTABLE WEDGE (qty: x5)
87	59009	LID CAP
88	59527	BLADE SPACER 15.5MM (NEW MODEL)
89	~~59530~~ 117952S	STRAIGHT BLADE (NEW MODEL)
90	~~59535~~ 118243S	FINE SERRATED BLADE (NEW MODEL)
91	~~59539~~ 118287S	SERRATED BLADE (NEW MODEL)
92	59081	SHAFT SEAL KIT COMPLETE R45A/R60A
93	59080	INTERNAL SHAFT SEAL KIT R45A/R60A
94	59498	MOTOR DEFLECTOR 45/60
95	59567	UPPER DEFLECTOR AND TORIC SEAL ASSEMBLY 45/60
96	59082	STAINLESS STEEL SCREW M6X16
97	59136	VCM FRAME HOLE CLOSER KIT
98	59553	HANDLE AXIS ASSEMBLY VCM
99	59555	THROUGH NECK RING ASSEMBLY 45/60
100	59378	COMPLETE MOTOR SHAFT SEALING ASSEMBLY R45-R60


kliknij w czerwone pole, aby zobaczyć/zamówić część

robot coupe®


R 45 A
R 45 A V.V.


N° de série / Serial number
- 612 - - - - - - -
- 624 - - - - - - -


R 45 A



R 45 A V.V.







robot coupe

R45A

Diagram n°2

Index PDF	Référence	Designation commerciale	Tarif
A	117995	CONTROL PANEL ASSEMBLY R45/R60 400/50	
B	503972S	TRANSFORMER 9/24V	
C	503356S	BREAK FUSE 20A	
D	507203S	OVER RELAY LRD 22 TESYS	
E	503108S	PRIMARY FUSE 5X20 6,3AT	
F	503362S	CONTACTOR D25	
G	503362S	CONTACTOR D25	
H	511620S	TRANSFORMER 25A	
I	59482	CONTROL + TIMER PLATE	
L	59145	SWITCH COMMAND PANEL ASSEMBLY	
1	500537S	PRIMARY FUSE 9/24V	
2	504253S	SECONDARY FUSE 9V	
3	507121S	SECONDARY FUSE 24V	
4	117980S	CONNECTION BOARD	
5	503973S	TRANFORMER 48V	
6	503362S	CONTACTOR D25	
7	117982S	FLAT LINK CABLE	
8	59271	[Spare parts translation not found]	
9	59247	SELF WIRES	
10	59249	FILTRE	
11	59212	ANALOG IMPUT WIRE	
12	59345	[Spare parts translation not found]	