
**ТЕРМОС ДЛЯ РИСА HURAKAN HKN-RT210**



| Поз | Наименование детали | Кол |
|---|---|---|
| 1 | Power Cord/P1ug | 1 |
| 2 | Power Cord Clip | 1 |
| 3 | Plastic Feet | 5 |
| 4 | Tottom Cover | 1 |
| 5 | Bottom Kcop Warm Cotton | 2 |
| 6 | Body Kcop Warm Cotton | 2 |
| 7 | Plastic Handle Fixed Frame | 1 |
| 8 | Cord Tube | 1 |
| 9 | TRS Thermostat | 1 |
| 10 | Fuse | 1 |
| 11 | Bottom Heating Ring | 1 |
| 12 | Upper Heating Ring | 1 |
| 13 | Inne Liner | 1 |
| 14 | Pot Fixde Ring | 1 |
| 15 | Inner Pot | 1 |
| 16 | Inner Pot Handle | 2 |
| 17 | Thermostat Basket | 1 |
| 18 | Body Fixde Plastic | 1 |
| 19 | Body Fixed Plastic Frame | 2 |
| 20 | Stainless Sceel Enclosure | 1 |
| 21 | Inner Cover | 1 |
| 22 | Inner Cover Rubber Gasket | 1 |
| 23 | Inner Cover Bar | 1 |
| 24 | Inner Lid Rubber Gasket | 2 |
| 25 | The Top Heater Fixed Tray | 1 |
| 26 | Seal completely a turn | 1 |
| 27 | Inner Lid Earth Wire | 1 |
| 28 | Top Cover Heating Ring | 1 |
| 29 | Pot Cover Fixed Ring | 1 |
| 30 | Lid Keep Warm Cotton | 1 |
| 31 | Lid/Pot Cover | 1 |
| 32 | Nut | 1 |
| 33 | Screw | 1 |
| 34 | Lid Plastic Fixture Frame | 1 |
| 35 | Light Cover | 1 |
| 36 | Lid Handle Cover | 1 |
| 37 | Indicating Light | 1 |
| 38 | Pot Pedesta1 | 1 |
| 39 | Lid Lock Pressing Pad | 1 |
| 40 | Lid Locd Case | 1 |
| 41 | Small Axis | 1 |
| 42 | Lid Srping | 1 |
| 43 | Spring Holder | 1 |
| 44 | Lid Lock Pad | 1 |
| 45 | Lid Locd Board | 1 |